









MAINTENANCE MANUAL


INSTANDHALTUNGSANLEITUNG
MANUEL D'ENTRETIEN
ISTRUZIONI PER LA MANUTENZIONE

**KNOW
HOW**
INSTALLED




**1****1****2****3****4****5**

6





7




2


1




2




3





4




7




5




8





6



9




10











1




Example

4 l




(EN 14055)	Typ 380 X [mm]	Typ 383 X [mm]
4 l	4.5	-5
5 l	4.5	38
6 l	6	32
7 l	7.5	32



NOTE:

Not applicable for US installations. Flush volume modifications shown are a violation of US law. **DO NOT ATTEMPT!**





Geberit International AG
Schachenstrasse 77, CH-8645 Jona
documentation@geberit.com
www.geberit.com